

LINKOSITY™ 10 AMP POWER SUPPLY CORDS AND TEE'S

INSTALLATION INSTRUCTIONS


GENERAL INFORMATION

- NOTICE:** For installation by a qualified electrician in accordance with national and local electrical codes and the following instructions.
- CAUTION: RISK OF ELECTRIC SHOCK. Disconnect power before installing. Never wire energized components.**
- NOT FOR INTERRUPTING CURRENT. DO NOT CONNECT OR DISCONNECT UNDER LOAD.
- CAUTION: To ensure seal of enclosure to Type ratings, tighten coupling nut firmly against mating connector. This connector is rated Enclosure Types 4, 4X, 12, 13 when fully connected to a mating Linkosity™ connector or receptacle having an equivalent Enclosure Type rating.**
- Check that the devices' Enclosure Type Rating and electrical ratings are suitable for the application.


INSTALLATION & USE

- Do not connect to power before conducting the following electrical tests:
 - Test continuity of wiring to verify correct polarity and phasing.
 - Measure insulation resistance to be sure the system does not have any short circuits or unwanted grounds.
- CAUTION: If any parts of the connector or cable appear to be missing, broken or show signs of damage: DISCONTINUE USE IMMEDIATELY! Replace damaged component. Failure to could cause serious injury or equipment damage.**
- Coupling nuts to be hand tight.
- For fixed applications, coupling nuts must be wrench tight - 1/4 turn beyond hand tight.

CONTACT LOCATIONS FOR LINKOSITY™ CONNECTORS MALE FACE VIEW



WIRING CODE FOR LINKOSITY™ CONNECTORS FEMALE FACE VIEW



Linkosity™ is a trademark of Lockheed Martin.

Wiring Device-Kellems
 Hubbell Incorporated (Delaware)
 185 Plains Road
 Milford, CT 06460-8897
 (203) 882-4800

PD2038

(Page 1)

3/09

